



J11 - selects the board base address. The MSB is the pins on the right. A jumper across the pins forms a 1. No jumper is a 0.

No other jumpers should be changed without consulting an expert.

SIZE A	REV	DRAWING #
-----------	-----	-----------

DWN BY Eleanor Judd	DATE 12/19/03	SCALE	UC Berkeley - Space Sciences Laboratory Crawford Group
	COG. ENG. Eleanor Judd	DATE	
ALL SCREW THREADS PER ANSI 14.6 BREAK EDGES 0.020 MAX ON MACHINE WORK. REMOVE BURRS, LOOSE SCALE AND WELD SPLATTER REFERENCE - ANSI 14.5 & B46.1		UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE INCHES DECIMAL TOLERANCES .X = ±0.06 .XX = ±0.02 .XXX = ±0.004	TITLE TCU Hardware switch settings
		ANGULAR TOLERANCE ± 1 DEG.	